



2007 RAVEN 1 LINE ALPHA PROGRAMMING GUIDE

- | |
|--|
| <ul style="list-style-type: none">• <i>FAR LEFT (RED) BUTTON IS THE FUNCTION KEY</i> |
| <ul style="list-style-type: none">• <i>MIDDLE (YELLOW) BUTTON IS THE SHIFT KEY</i> |
| <ul style="list-style-type: none">• <i>FAR RIGHT (GREEN) IS THE READ KEY</i> |

1. TURN THE PAGER OFF. THEN HOLD DOWN THE FUNCTION KEY AND THE SHIFT KEY. DO NOT RELEASE THE FUNCTION OR READ KEY UNTIL YOU SEE A SCREEN THAT DISPLAYS **EEPR** PRESS THE SHIFT KEY TO DISPLAY **00000**. ATI PRESETS THIS PASSWORD TO **80000**. PRESS THE SHIFT KEY TO CHANGE THE FIRST NUMBER TO AN 8. ONCE THE FIRST NUMBER IS CHANGED TO AN 8 USE THE SHIFT KEY TO SCROLL THROUGH THE REMAINING DIGITS. ONCE YOU GET TO THE LAST 0 PRESS THE READ KEY. THIS WILL ENTER YOU INTO THE MANUAL-PROGRAMMING MODE.

2. YOU WILL ENTER A SCREEN THAT WILL DISPLAY **-RIC-** PRESS THE READ KEY. YOU ENTER A SCREEN THAT WILL DISPLAY **-1- 1234567** THIS IS WHERE YOU CHANGE YOUR CAPCODE. PRESS THE FUNCTION KEY TO SCROLL TO THE NEXT NUMBER, PRESS THE SHIFT KEY TO CHANGE THE DATA. ONCE YOUR CAPCODE IS ENTERED GO **-1-** THEN PRESS THE SHIFT KEY. THIS WILL TAKE YOU TO THE NEXT CAPCODE. REPEAT THIS STEP FOR CAPCODE ADDRESSES 2-6. ONCE ALL CAPCODES ARE ENTERED PRESS THE READ KEY. YOU WILL GO TO **-RIC-** ONCE AGAIN. PRESS THE FUNCTION KEY.

3. YOU WILL ENTER A SCREEN THAT WILL DISPLAY **-NUC-**. YOU WILL ENTER A SCREEN THAT WILL DISPLAY **1.A 2.A 3.A 4.A 5.A 6.A**. THIS IS WHERE YOU CAN CHANGE EACH CAPCODE TO A NUMERIC OR ALPHANUMERIC ADDRESS. PRESS THE PRESS THE FUNCTION KEY ONCE AGAIN TO EXIT.

4. YOU WILL ENTER A SCREEN THAT WILL DISPLAY **-BPS-** THIS IS WHERE YOU SET THE BAUD RATE FOR THIS UNIT. PRESS THE FUNCTION KEY UNTIL YOU SEE YOUR DESIGNATED BAUD RATE 512bps, 1200bps or 2400bps. PRESS THE READ KEY ONCE THE BAUD RATE IS SET. THEN PRESS THE FUNCTION KEY.

5. YOU WILL ENTER A SCREEN THAT WILL DISPLAY **-POL-** **THIS FUNCTION SHOULD ALWAYS BE SET TO NOR FOR NORMAL** IF THIS FUNCTION IS SET TO **INV** YOU WILL NOT RECEIVE ANY MESSAGES. YOU WILL NEED TO CHANGE THIS SETTING TO **NOR** THIS IS

POSSIBLE BY PRESSING THE FUNCTION KEY UNTIL THE SCREEN DISPLAYS **NOR** ONCE THIS CHANGE IS MADE PRESS THE READ KEY. THEN PRESS THE FUNCTION KEY.

6. YOU WILL ENTER A SCREEN THAT WILL DISPLAY **END**. IF YOU NEED TO MAKE ANY FURTHER CHANGES TO THIS UNIT PRESS THE FUNCTION KEY. TO SAVE THE CHANGES YOU HAVE MADE PRESS THE SHIFT KEY THREE TIMES. ONCE YOU PRESS THE SHIFT KEY THREE TIMES THE UNIT WILL RESTART. YOU HAVE COMPLETED THE MANUAL PROGRAMMING FOR THIS UNIT. PLEASE TEST THE UNIT TO MAKE SURE ALL CHANGES THAT WERE MADE ARE CORRECT.